



SHEAVE

HUB

THREAD HUB FIRST 14 TPI
 THEN BORE SHEAVE AND THREAD TO FIT
 SCREW IN AND LOCTITE WITH 271 FOLLOWED WITH
 DRILLING AND PINING WITH TWO DUTCH PINS